



## BP06-12

BP06-12 – Batteria al piombo 6V 12Ah - AGM



## BP06-7

BP06-7 – Batteria al piombo 6V 7Ah - AGM



## BP12-100

BP12-100 – Batteria al piombo 12V 100Ah - AGM



## BP12-12

BP12-12 – Batteria al piombo 12V 12Ah - AGM



## BP12-150

BP12-150 – Batteria al piombo 12V 150Ah - AGM



## BP12-18

**BP12-18** – Batteria al piombo 12V 18Ah - AGM



## BP12-200

**BP12-200** – Batteria al piombo 12V 200Ah - AGM



## BP12-26

**BP12-26** – Batteria al piombo 12V 26Ah - AGM



## BP12-44

**BP12-44** – Batteria al piombo 12V 44Ah - AGM



## BP12-10

**BP12-10** – Batteria al piombo 12V 10Ah - AGM



## BP12-33

BP12-33 – Batteria al piombo 12V 33Ah - AGM



## BP12-55

BP12-55 – Batteria al piombo 12V - 55Ah - AGM



## BP12-2.9

BP12-2.9 – Batteria al piombo 12V 2,9Ah - AGM



## BP06-3.2

BP06-3.2 – Batteria al piombo 6V 3,2Ah - AGM



## BP12-3.4

BP12-3.4 – Batteria al piombo 12V 3,4Ah - AGM



## BP12-4.5

BP12-4.5 – Batteria al piombo 12V 4,5Ah - AGM



## BP12-10/6.3

BP12-10/6.3 – Batteria al piombo 12V 10Ah - AGM



## BP12-1.3

BP12-1.3 – Batteria al piombo 12V 1,3Ah - AGM



## BP12-2.2

BP12-2.2 – Batteria al piombo 12V 2,2Ah - AGM



## BP06-4

BP06-4.5 – Batteria al piombo 6V 4,5Ah - AGM

BP06-4.0 – Batteria al piombo 6V 4,0Ah - AGM



## BP06-3.4

BP06-3.4 – Batteria al piombo 6V 3,4Ah - AGM



## BP06-1.3

BP06-1.3 – Batteria al piombo 6V 1,3Ah - AGM



## BP12-5

BP12-5.0 – Batteria al piombo 12V 5,0Ah - AGM



## BP04-3.0

BP04-3.0 – Batteria al piombo 4V 3,0Ah - AGM